



Tursdale Technical Services Ltd
Unit N12B
Tursdale Business Park
Co. Durham
DH6 5PG
United Kingdom
Phone: +44 (0) 191 377 3398
Fax: +44 (0) 191 377 3357
info@tursdaletechnicalservices.co.uk
<http://www.industrial-needs.com/>

MANUAL PCE-IT 100



Safety symbols:.....	3
1.SPECIFICATIONS.....	4
1.1General Information Environment conditions:	4
Maintenance & Clearing:.....	4
Display: Large LCD with dual display.....	4
Measurement Range	4
Sampling Rate	4
Zero Adjustment:.....	4
Over Range Indicator.....	4
Low Battery Indication:	4
Operating Temperature	4
Storage Temperature.....	4
Power source	4
Dimensions:.....	4
Weight.....	4
Accessories.....	4
1.2 Electrical Specifications.....	5
OHMS.....	5
Continuity Beeper.....	5
DC Voltage	5
AC Voltage (40Hz~400Hz)	5
Meg OHMS.....	5
2. PARTS & CONTROLS.....	6
2-1 How to connect test leads.....	6
2-2 Battery Check-UP & Replacement.....	6
2-3 Test leads check.....	6
2-4 Rotary Switch positions.....	6
2-5 Buttons and a display Indicators.....	7
a). Button.....	7
b).Display Indicators	7
3. INSULATION RESISTANCE MEASUREMENTS	8
4.LOW RESISTANCE (CONTINUITY) MEASUREMENTS	8
5.AC/DC VOLTAGE MEASUREMENTS.....	8
6.BATTERY SAVER (SLEEP MODE).....	9
7.POWER TOOLS AND AMALL APPLIANCES.....	9
MOTORS.....	9
CABLES	9

SAFETY INFORMATION

- Read the following safety information carefully before attempting to operate or service the meter.
- To avoid damages to the instrument do not apply the signals which exceed the maximum limits shown in the technical specifications tables.
- Do not use the meter or test leads if they look damaged. Use extreme caution when working around bare conductors or bus bars.
- Accidental contact with the conductor could result in electric shock.
- Use the meter only as specified in this manual; otherwise, the protection provided by the meter may be impaired.
- Read the operating instructions before use and follow all safety Information.
- Caution when working with voltages above 60V DC or 30V AC RMS. Such voltages pose a shock hazard.
- Before taking resistance measurements or testing acoustic continuity, disconnect circuit from main power supply and all loads from the circuit.

Safety symbols:



Caution refer to this manual before using the meter.



Dangerous voltages.



Meter is protected throughout by double insulation or reinforced insulation.

When servicing, use only specified replacement parts.

CE Comply with EN-61010-1

1. SPECIFICATIONS

1.1 General Information Environment conditions:

- ① Installation Categories
- ② Pollution Degree 2
- ③ Altitude up to 2000 meters
- ④ Indoor use only
- ⑤ Relatively humidity 80% max.
- ⑥ Operation Ambient 0~40°C

Maintenance & Clearing:

- ① Repairs or servicing not covered in this manual should only be performed by qualified personnel.
- ② Periodically wipe the case with a dry cloth. Do not use abrasives or solvents on this instruments.


Display: Large LCD with dual display

Measurement Range: 4000M Ω /125V, 4000M Ω /250V, 4000M Ω /500V, 4000M Ω /1000V, 400 Ω /BZ,
1000V/DCV, 750V/ACV

Sampling Rate: 2.5 times per second.

Zero Adjustment: Automatic adjustment.

Over Range Indicator: "OL" of highest digit is displayed.

Low Battery Indication: The  is displayed when the battery Voltage drop below the operating voltage.

Operating Temperature: 0°C to 40°C (32°F to 104°F) and Humidity below 80% RH

Storage Temperature: -10°C to 60°C (14°F to 140°F) and Humidity below 70% RH

Power source: DC9V (6x1.5V Size "AA" battery or Equivalent)

Dimensions: 200(L) x 92(W) x 50(H) mm

Weight: Approx 700g include battery

Accessories: Test leads, 6pcs battery, Carrying case, manual.

1.2 Electrical Specifications

Accuracies are specified in the way:

$\pm(\dots\%$ of reading $+\dots$ digits) at $23^{\circ}\text{C}\pm 5^{\circ}\text{C}$, below 80% RH.

OHMS

Range	Resolution	Accuracy	Max. open Circuit Voltage	Overload Protection
40.00 Ω	0.01 Ω	$\pm(1.2\%+3)$	5.8V	250Vrms
400.0 Ω	0.1 Ω		5.8V	

Continuity Beeper

Range	Resolution	Operation Resistance	Max.open Circuit Voltage	Overload Protection
•)))	0.01 Ω	Resistance $\leq 35\Omega$	5.8V	250Vrms
Short circuit current		$\geq 200\text{mA}$		

DC Voltage

Range	Resolution	Accuracy	Input Impedance	Overload Protection
1000V	1V	$\pm(0.8\%+3)$	10M Ω	1000Vrms

AC Voltage (40Hz~400Hz)


Range	Resolution	Accuracy	Input Impedance	Overload Protection
750V	1V	$\pm(1.2\%+10)$	10M Ω	750Vrms

Meg OHMS

Terminal Voltage	Range	Resolution	Accuracy	Test Current	Short circuit current
125V(0%~+10%)	0.125~4.000 M Ω	0.001M Ω	$\pm(2\%+10)$	1mA @load125k Ω	$\leq 1\text{mA}$
	4.001~40.00 M Ω	0.01M Ω	$\pm(2\%+10)$		
	40.01~400.0 M Ω	0.1M Ω	$\pm(4\%+5)$		
	400.1~4000 M Ω	1M Ω	$\pm(5\%+5)$		
250V(0%~+10%)	0.250~4.000 M Ω	0.001M Ω	$\pm(2\%+10)$	1mA @load250k Ω	$\leq 1\text{mA}$
	4.001~40.00 M Ω	0.01M Ω	$\pm(2\%+10)$		
	40.01~400.0 M Ω	0.1M Ω	$\pm(3\%+5)$		
	400.1~4000 M Ω	1M Ω	$\pm(4\%+5)$		
500V(0%~+10%)	0.500~4.000 M Ω	0.001M Ω	$\pm(2\%+10)$	1mA @load500k Ω	$\leq 1\text{mA}$
	4.001~40.00 M Ω	0.01M Ω	$\pm(2\%+10)$		
	40.01~400.0 M Ω	0.1M Ω	$\pm(2\%+5)$		
	400.1~4000 M Ω	1M Ω	$\pm(4\%+5)$		
1000V(0%~+10%)	1.000~4.000 M Ω	0.001M Ω	$\pm(3\%+10)$	1mA @load1M Ω	$\leq 1\text{mA}$
	4.001~40.00 M Ω	0.01M Ω	$\pm(2\%+10)$		
	40.01~400.0 M Ω	0.1M Ω	$\pm(2\%+5)$		
	400.1~4000 M Ω	1M Ω	$\pm(4\%+5)$		

2. PARTS & CONTROLS


1. Digital Display
2. Data Hold Button; MAX/MIN
3. Lock Button
4. Backlight Button; ZERO
5. Test Button
6. Rotary Function switch
7. VΩ Jack
8. COM input jack
9. Pothook
10. Battery Cover



2-1 How to connect test leads.

On MΩ Range , and 400Ω/BZ ,ACV,.DCV, Connect the red test lead into the “VΩ” terminal and the black lead into the “COM” terminal.

2-2 Battery Check-UP & Replacement

- a) As battery power is not sufficient. LCD will display . Replacement of 6 pcs new batteries, type 1.5V size “AA” is Required.
- b). Place back the battery cover and four the screws.

2-3 Test leads check

Set the range select switch to the 400Ω range. With the tip and alligator clip of the test leads connected. The indicator should read 00.0Ω. When the leads are not connected the display will read infinity indicated by “OL”. This will ensure that test lead are under working condition.

2-4 Rotary Switch positions

Turn the Tester on by selecting any measurement

Lift < 1000v,500v,250v,125v (4000MΩ)

OFF 400Ω/BZ, 1000VDC,750VAC > Right

2-5 Buttons and a display Indicators

a). Button

HOLD/MAX.MIN : Instant-pressing the “HOLD” button the 1st time, the current values will be hold in the primary display., but it will return in the 2nd pressing ; pressing 2 seconds ,it will enter directly into the “MAX” status, and one another instant-pressing will switch to the “MIN”, if instant-pressing once more, it will recycle ,but exit if pressing 2 seconds again.

LOCK : In the insulation resistance testing function ,press the “LOCK” button ,and then push down the “TEST” key, it will occur the high-voltage and enter the insulation resistance testing status. Press the “TEST” button once more ,it will shutoff the high-voltage and exit from the insulation resistance testing status.

TEST : In the insulation resistance testing function ,pressing and holding the “TEST” button, The meter will bring high-voltage, and enter into the insulation resistance testing, being free from the “TEST” , it will cutoff the high-voltage and exit form the insulation resistance testing.

ZERO/LIGHT : instant-pressing the “ZERO/LIGHT” button in the 1st time, the current values in the primary display will be set zero,(mainly used for 400 Ω , the low resistance testing), ,it will return if in the 2nd time. pressing for 2 seconds, it will enter directly into the “LIGHT” status, and the LCD backlight light up. After 15 seconds, the backlight is shut off automatically, the same as pressing for 2 seconds within 15s.

b).Display Indicators

The Primary Display: Indicate the current function testing values The Secondary Display : It shows the output DCV while you test the insulation resistance, and the battery voltage while the ACV The Analog Bar: indicate the current function testing value in synchronous with the primary display.

“ Ω ” :While testing the insulation resistance, the symbol

“ Ω ” flashes frequently if the voltage is over 30V.

“•••••” :While testing the insulation resistance, the symbol “•••••” flashes frequently and the buzzer warns continually if the outside voltage is over 30V. the symbol “•••••” is indicated while $LO\Omega \leq 35\Omega$ and the BZ warns continuously.

LOCK: Push down the “LOCK” button while you test the insulation resistance and the symbol “ Ω_{LOCK} ” is indicated. LOBAT The display shows “LOBAT” when the voltage drops below 7.5V

MAX/MIN: Stand for the maximum or the minimum.

ZERO : Digital zero adjusting

HOLD : The digital holding function for the primary display.

AC,DC: The indicator for the voltage property.

V,M Ω , Ω : The measured dimension units

3. INSULATION RESISTANCE MEASUREMENTS

- a) Turn the function switch from the "OFF" position to the left (4000 M Ω /1000V---4000/ M Ω 500V---4000 M Ω /250V---1000 M Ω /125V) ,and chose one of the voltage-block(there are 4 ranges namely, 4 M Ω 40 M Ω 400 M Ω 4000 M Ω , can be switched automatically for every voltage-block.)
- b) Connect two testing lines to the tested ;
- c) Push down and hold the "TEST" button /or press the " LOCK" keystroke first and then the "TEST" button, if the tested is electriferous and its voltage (AC/DC) is over 30V, it will refuse work and no high-voltage testing occurs, simultaneity, it shows ">30V" on the LCD, the symbol " ⚡ " flashes, and the buzzer warns frequently. if the tested is diselectriferous or its voltage is lower than 30V, it will enter into the formal testing process and brings the high-voltage. on the primary display, the insulation resistance in M Ω is indicated in-phase with analog bar; on the secondary display, the tested insulation voltage in V (DC) is indicated, the symbol " ⚡ " flashes and the buzzer warns frequently
- d) Being free from the "TEST" button or pushing down the "TEST" button in the "LOCK " status can exit from the "LOCK" status and shutoff the high-voltage□synchronously, the resistance values is indicated in the primary display will be held, and the secondary display still be in the status of monitoring the insulation voltage for the tested.
- e) Subsequently, discharge the balance insulation voltage of the tested through the inner switch of the meter. Turning the function switch can exit automatically from testing status during the process.

4. LOW RESISTANCE (CONTINUITY) MEASUREMENTS

- a). Set the range switch to 400 Ω /BZ Position
- b). Connect the red test lead to the V Ω terminal and black to the COM terminal.
- c). Connect the tips of the test leads to both ends of the circuit under test. read resistance in Ω on the LCD. The two ranges(40.00/400.0 Ω) can be switched automatically; the primary display of the resistance in Ω , flashes in synchronous with the analog bar.
- d). When the impedance on circuit is below approximately $\leq 35\Omega$.It will indicate by a continuous beeper.
- e) The current is from 200 to 220mA while the tested resistance is 0 Ω
- f) The high voltage symbol " ⚡ " flashes along with a primary display of ">30V" and the buzzer warns frequently if the voltage (AC/DC) is more than 30V.

5.AC/DC VOLTAGE MEASUREMENTS

- a). Set the range switch to ACV or DCV position
- b). Connect red test lead to "V Ω " terminal and black test lead to terminal "COM".
- c). Connect test prods of test leads IN PARALLEL to the circuit being measured.
- d). Read the voltage value on LCD.

6. BATTERY SAVER (SLEEP MODE)

The meter will automatically enter the "sleep mode" if there is no function change or button press for 10 minutes, but it works as soon as you turn the rotary function switch or push down any button.


7. POWER TOOLS AND SMALL APPLIANCES

This test would also apply to other similar equipment that has a line cord. For double insulated power tools, the megohmmeter lead shown connected to the housing would be connected to some metal part of the tool (e.g. chuck, blade).

Note: The switch of the device must be in the "ON" position and the main power should be disconnected.


MOTORS

AC-Disconnect the motor from the line by disconnecting the wires at the motor terminals or by opening the main switch. If the main switch is used and the motor also has a starter then the starter must be held, by some means, in the "ON" position. In the latter case, the measured resistance will include the resistance of the motor, wire and all other components between the motor and the main switch. If a weakness is indicated, the motor and other components should be checked individually. If the motor is disconnected at the motor terminals, connect one megohmmeter lead to the grounded motor housing and the other lead to one of the motor leads. DC-Disconnect the motor from the line. To test the brush rigging, field coils and armature connect one megohmmeter lead to the grounded motor housing and the other lead to the brush on the commutator. If the resistance measurement indicates a weakness, raise the brushes off the commutator and separately test the armature, field coils and brush rigging by connecting one megohmmeter lead to each of them individually, leaving the other connected to the grounded motor housing. The above also applies to DC Generators.



CABLES

Disconnect the cable from the line. Also disconnect opposite end to avoid errors due to leakage from other equipment. Check each conductor to ground and /or lead sheath by connecting one megohmmeter lead to a ground and /or lead sheath and the other megohmmeter lead to each of the conductors in turn. Check insulation resistance between conductors by connecting megohmmeter leads to conductors in pairs.



In this direction will find a vision of the measurement technique:
<http://www.industrial-needs.com/measuring-instruments.htm>

NOTE: "This instrument doesn't have ATEX protection, so it should not be used in potentially explosive atmospheres (powder, flammable gases)."